

User manuals: light stands, R range

Notice d'utilisation : élévateurs gamme R

Bedienungsanleitung: Teleskopstative, R serie



1. Introduction

This user manual has been written as guidance for a safe and efficient use of your Goliath-studio R light stand. We strongly recommend you read carefully and implement all instructions given in this document.

Our products benefit from quality inspections and demanding tests procedures during the manufacturing process. The R range has a 1 year warranty from date of shipment providing it is used in accordance of this instruction manual and within the limit of a normal use (see our conditions of warranty).

Goliath Studio provides several type of maintenance and after sales service contract as well as warranty extension and yearly certifications for your Goliath Studio lifters. These programs provide longer life to your lifter while confirming the upmost level of security for you and the using personnel. We strongly recommend to subscribe.

2. Technical data

Light stands restricted use to entertainment light system management only. All other use is forbidden.

Série R	R2400	R3500	R4000	R4700	R5200
Maximum load	100 kg	100 kg	120 kg	150 kg	200 kg
Minimum load	10 kg	10 kg	10 kg	10 kg	10 kg
Maximum height	2400 mm	3450 mm	3800 mm	4715 mm	4950 mm
Folded height	1070 mm	1600 mm	1385 mm	1855 mm	1855 mm
Weight	16 kg	19 kg	30 kg	62 kg	69 kg
Foot extention dia.	1200 mm	1200 mm	1500 mm	2000 mm	2000 mm
Number of sections	2	2	3	3	3

All Pro models benefit from a rack and pinion elevation design with automatic safety system.

The upper sections move simultaneously and evenly up.

The additional automatic safety system comes as a standard on the 3rd section.

Front legs are individually adjustable to guarantee an excellent stability.

Each foot is equipped with rubber block.

Corrosion free: Hard anodised aluminium and galvanised painted steel.