


HEADSHELL MODEL	Headshell length	Headshell width	Mounting distance max.	Mounting distance min.	Screw diameter max.
<b>SH-4</b>	51.5 mm	20.0 mm	44.0 mm	35.0 mm	3.0 mm
<b>LH-2000</b>	50.3 mm	20.0 mm	41.9 mm	32.5 mm	N/S
<b>LH-4000</b>			41.9 mm	32.5 mm	N/S
<b>LH-6000</b>	47.7 mm	19.1 mm	42.5 mm	37.2 mm	N/S
<b>LH-8000</b>	50.5 mm	19.0 mm	41.9 mm	32.5 mm	N/S
<b>LH-9000</b>	52.0 mm	20.0 mm	46.0 mm	38.0 mm	N/S
<b>LH-10000</b>	51.2 mm	19.4 mm	42.0 mm	42.0 mm	2.7 mm



**A - Headshell length**

**B - Headshell width**

**C - Mounting distance max.**

**D - Mounting distance min.**

**E - Screw diameter max.**